





Schurter



SCHURTER
ELECTRONIC COMPONENTS


CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S

Hlutanúmer:	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSH SPST-NO 100MA 42V
Gagnablöð:	 CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S.pdf
RoHS Staða	 Leiða frjáls / RoHS samhæft
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.













Upplýsingar um CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S

HLUTANÚMER	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSH SPST-NO 100MA 42V
LEIÐA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
GÖGN	 CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-Mom
RÖÐ	CPS
PALLBORDSMET	Circular - 19.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARNÆMISSTIG (MSL)	1 (Unlimited)
VÉLÆN LÍF	-
LEIÐA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÁRÁRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓÐ SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Blue/Red
LÖGUN	8 Symbol
RAFMAÐAGSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Silver
HRINGRÁS	SPST-NO
VIRKJUNARGERÐ	Round, Button, Flush

Svipaðir merkingar

Schurter CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S dreifingaraðili	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S birgir
CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S verð	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S Myndir	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S mynd
CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S PDF gagnablað	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S niðurhal gagnablað	CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S gagnablað
CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S lager	Kauptu CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S	Kauptu Schurter CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S
Schurter CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S	Schurter birgir	Schurter dreifingaraðili
Schurter CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S	Schurter Inc. CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1035-S	

skyldar vörur

 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1037-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1033-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1039-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1032-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1029-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1038-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1030-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1041-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1031-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1040-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1036-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p>CPS19-NO00A10-SNCSNCNF-RI0BRVAR-W1034-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>