






## CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S

Hlutanúmer:	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSHBUTTON SPST 100MA 42V
Gagnablöð:	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S.pdf
RoHS Staða	 Leiða frjáls / RoHS samhæft
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

### Upplýsingar um CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S

HLUTANÚMER	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSHBUTTON SPST 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
GÖGN	 CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-On
RÖÐ	CPS
PALLBORDSMET	Circular - 19.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARNÆMISSTIG (MSL)	1 (Unlimited)
VÉLÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÁRÁRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓÐ SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Yellow/Cyan
LÖGUN	Ceramic Actuator, N Symbol
RAFMAGNLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Clear (White Filter/Diffuser)
HRINGRÁS	SPST
VIRKJUNARGERÐ	Round, Button, Flush

### Svipaðir merkingar

Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S dreifingaraðili	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S birgir
CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S verð	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S Myndir	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S mynd
CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S PDF gagnablað	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S niðurhal gagnablað	CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S gagnablað
CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S lager	Kauptu CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S	Kauptu Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S
Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S	Schurter birgir	Schurter dreifingaraðili
Schurter CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S	Schurter Inc. CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1014-S	

### skyldar vörur

 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1011-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1009-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1015-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1008-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1012-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1018-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1010-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1019-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1013-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1020-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>
 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1017-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>	 <p><b>CPS19-LA00A10-SNCCWTNF-AI0YCVAR-W1016-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p><b>RFQ</b></p>