




CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S

Hlutanúmer:	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSHBUTTON SPST 100MA 42V
Gagnablað:	PDF CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S.pdf
RoHS Staða	 Leiða frjáls / RoHS samhæft
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

Upplýsingar um CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S

HLUTANÚMER	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSHBUTTON SPST 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
GÖGN	PDF CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-On
RÖÐ	CPS
PALLBORDSMET	Circular - 19.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARNÆMISSTIG (MSL)	1 (Unlimited)
VÉLÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÁRÁRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓÐ SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Cyan/Magenta
LÖGUN	Ceramic Actuator, Finger Guide, U Symbol
RAFMAAGSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Clear (White Filter/Diffuser)
HRINGRÁS	SPST
VIRKJUNARGERÐ	Round, Button, Flush

Svipaðir merkingar

Schurter CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S dreifingaraðili	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S birgir
CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S verð	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S Myndir	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S mynd
CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S PDF gagnablað	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S niðurhal gagnablað	CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S gagnablað
CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S lager	Kauptu CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S	Kauptu Schurter CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S
Schurter CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S	Schurter birgir	Schurter dreifingaraðili
Schurter CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S	Schurter Inc. CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1021-S	

skyldar vörur

 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1019-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>	 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1026-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>
 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1022-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>	 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1025-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>
 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1018-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>	 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1027-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>
 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1016-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>	 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1017-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>
 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1024-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>	 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1020-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>
 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1023-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>	 <p>CPS19-LA00A10-SNCCWTF-AI0CMVAR-W1015-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p>RFQ</p>