





**Schurter**



**SCHURTER**  
ELECTRONIC COMPONENTS


## CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S

Hlutanúmer:	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSHBUTTON SPST 100MA 42V
Gagnablað:	 CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S.pdf
RoHS Staða	 Leiða frjáls / RoHS samhæft
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

### Upplýsingar um CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S

HLUTANÚMER	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSHBUTTON SPST 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
GÖGN	 CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-On
RÖÐ	CPS
PALLBORDSMET	Circular - 22.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARNÆMISSTIG (MSL)	1 (Unlimited)
VÉLÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÁRÁRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓÐ SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Blue/Yellow
LÖGUN	Finger Guide, Equals Symbol
RAFMAGNSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Silver
HRINGRÁS	SPST
VIRKJUNARGERÐ	Round, Button, Flush

### Svipaðir merkingar

Schurter CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S dreifingaraðili	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S birgir
CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S verð	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S Myndir	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S mynd
CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S PDF gagnablað	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S niðurhal gagnablað	CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S gagnablað
CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S lager	Kauptu CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S	Kauptu Schurter CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S
Schurter CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S	Schurter birgir	Schurter dreifingaraðili
Schurter CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S	Schurter Inc. CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1042-S	

### skyldar vörur

 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1040-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1036-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1043-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1045-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1037-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1048-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1039-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1041-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1038-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1047-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1046-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0BYVAR-W1044-S</b></p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; font-weight: bold;">RFQ</p>