




## CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S

|                           |  |
|---------------------------|--|
| Hlutanúmer:               | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S  |
| Framleiðandi / Vörumerki: | Schurter   |
| Vörulýsing                | SWITCH PUSHBUTTON SPST 100MA 42V   |
| Gagnablað:                | <a href="#">PDF CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S.pdf</a>  |
| RoHS Staða                |  Leiða frjálts / RoHS samhæft |
| Skip frá                  | Hong Kong  |
| Sending vegur             | DHL/Fedex/TNT/UPS/EMS  |

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

### Upplýsingar um CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S

|                                 |   |
|---------------------------------|---|
| HLUTANÚMER                      | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S                           |
| FRAMLEIÐANDI                    | Schurter  |
| LÝSING                          | SWITCH PUSHBUTTON SPST 100MA 42V                                  |
| LEIÐA FRJÁLS STAÐA / ROHS STAÐA | Leiða frjálts / RoHS samhæft                                      |
| GÖGN                            | <a href="#">PDF CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S.pdf</a>   |
| SPENNAHLUTFALL - DC             | 60V   |
| SPENNA EINKUNN - AC             | 42V   |
| GERÐ                            | Capacitive, Illuminated   |
| UPPSAGNARSTÍLL                  | Wire Leads  |
| ROFI VIRKA                      | Off-On  |
| RÖÐ                             | CPS   |
| PALLBORDSMET                    | Circular - 16.10mm Dia  |
| PÖKKUN                          | Bulk  |
| VINNUHITASTIG                   | -40°C ~ 60°C  |
| UPPSETNINGARTEGUND              | Panel Mount, Front  |
| VÖKTUNARNÆMISSTIG (MSL)         | 1 (Unlimited)   |
| VÉLÆN LÍF                       | -   |
| LEIÐA FRJÁLS STAÐA / ROHS STAÐA | Lead free / RoHS Compliant  |
| INNÁRÁRVÖRN                     | IP67 - Dust Tight, Waterproof                                     |
| UPPLJÓÐ SPENNA (NAFNVERÐ)       | 5 ~ 28 VDC  |
| LÝSING LÝSINGAR, LIT.           | LED, Green/Red  |
| LÖGUN                           | Ceramic Actuator, Finger Guide, LOCK Symbol                       |
| RAFMAGNSLÍF                     | -   |
| NÁKVÆM LÝSING                   | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front |
| NÚVERANDI EINKUNN               | 100mA (AC/DC)   |
| LITUR - STÝRISBÚNAÐUR / LOKI    | Clear (White Filter/Diffuser)                                     |
| HRINGRÁS                        | SPST  |
| VIRKJUNARGERÐ                   | Round, Button, Flush  |

### Svipaðir merkingar

|   |  |   |
|---|--|---|
| Schurter CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S      | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S dreifingaraðili    | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S birgir          |
| CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S verð          | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S Myndir             | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S mynd            |
| CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S PDF gagnablað | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S niðurhal gagnablað | CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S gagnablað       |
| CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S lager         | Kauptu CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S             | Kauptu Schurter CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S |
| Schurter CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S      | Schurter birgir  | Schurter dreifingaraðili                                |
| Schurter CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S      | Schurter Inc. CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1056-S      |   |

### skyldar vörur

|   |  |
|---|--|
|  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1057-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1055-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |
|  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1058-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1052-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |
|  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1060-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1053-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |
|  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1061-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1051-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |
|  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1062-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1050-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |
|  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1054-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |  <p><b>CPS16-LA00A10-SNCCWTWF-AI0GRVAR-W1059-S</b></p> <p>Framleiðendur: Schurter<br/>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V<br/>Á lager: Out stock</p> <p><b>RFQ</b></p> |